

YEKATERINBURG/Koltsovo (SVX/USSS)

Elevation 766ft

CATEGORY A

AV brief availability

GENERAL

- Located 8 nm SE of Yekaterinburg in the eastern foothills of the central Urals on the banks of the lset River
- Also known by its old Soviet name of Sverdlovsk
- A well-equipped airfield which is one of the top seven busiest airports in Russia
- Standard R/T is recommended
- Large Easterly variation

Threats

CFIT

- The airport is surrounded by low hills which are heavily wooded
- Between the airport and the city are numerous smokestacks reaching almost 1,300 ft asl 7 nm WNW
- Hills W of the airport reach nearly 1,350 ft asl at 5 nm and almost 1,250 ft at 8 nm E

Runway Incursion

• Aramil Airport is 2 nm S. Do not confuse with Yekaterinburg.

Special Considerations

• Metric altimetry in use.

ARRIVAL

Diversion Airports			
CHELYABINSK	CEK/USCC	089 nm/164°T	CAT B
PERM	PEE/USPP	171 nm/296°T	CAT A
KHANTY-MANSIYSK	HMA/USHH	364 nm/042°T	CAT B

Approach

- Non standard ILS GP to Rwys 08R, 26L and 26R
- NDB approaches are available to all runways
- Clearance to intercept final approach will probably not be given, the aircraft being expected to make the last turn on to final without specific instructions
- Clearance to land given after crew have reported undercarriage down.



DEPARTURE

• Initial climb clearance may be to only 300m. Call airborne promptly for further climb from Radar as levelling off at 300 m may pose handling and A/T difficulties.

WEATHER

- Summer begins in June and is often hot with temperatures as high as 25°C and long stretches of dry, clear weather which can last until October
- Autumn is brief and winter begins with heavy snowfalls in mid-November
- Winter weather characterised by brief, heavy, dry snowfalls followed by long stretches of clear, sunny but very cold days. Temperatures can reach -18°C and remain there for weeks on end.
- Snow begins to thaw in March and typical springtime weather is chilly and damp.

OPERATIONAL INFORMATION

Handling Agent	Rusaero
Handling Agent VHF	
Potable Water	Uplift not permitted

IF ONLY Electrical Power is required	Use ground power at all times
If BOTH electrical power and air conditioning is required:	Use APU (ACU equipment not available). Keep GPU connected to reduce APU fuel burn.