

HONOLULU (HNL/PHNL)

Elevation 14ft

CATEGORY A/B/C

AV brief availability

GENERAL

- Daniel K. Inouye International Airport is the main and largest airport in Hawaii. The airport is located 5 km NW of Honolulu's central business district.

Threats

CFIT

- High terrain in a sector N of airport roughly 270 to 090 degrees. Comply with the turn restrictions on your SID.

Runway Incursion

- You will normally need to cross one or more active runways to get to and from the terminal. Use caution.

Loss of Control

- Bird strike hazard all runways.

Special Considerations

- LAHSO operations might be in effect for 8L and 4L. As you know, Simfest is not allowed to participate in such shenanigans.

ARRIVAL

Diversion Airports

KONA	KOA/PHKO	159 nm/131°T	CAT A
HILO	ITO/PHTO	222 nm/120°T	CAT A
KALAELOA	JRF/PHJR	265 nm/080°T	CAT A

- Plan to fly 210 kt on downwind and no less than 180 kt until the FAF.
- Remain on TWR frequency until instructed to monitor or call GND.

GROUND

- Complex airport with crossing runways and long taxi routes. Expect delays.

DEPARTURE

- You can expect PDC via pilot client text. If you have not received it within a reasonable time, contact ATC.
- East Ops: Departure Runways 8L/R, 4R
- West Ops: Departure Runways 22L, 26R
- Heavy Aircraft have to take off from 8R during East Ops and from 26R or 22L during West Ops.

- If parked at the Terminals or North Cargo, you should expect runway 8L/26R or 22L for departure
- As part of your takeoff clearance, you will be given an initial departure heading. Complete the turn before the distance (normally 2nm from Rwy departure end) listed on the SID chart. Accelerate to 250 kt without delay.

WEATHER

- Honolulu has a hot semi-arid climate, with a mostly dry summer season, due to a rain shadow effect. Temperatures are tropical but rainfall is not.
- Temperatures vary little throughout the year with average high temperatures of 27-32C and average lows of 18-24C. Rainfall occurs mainly between October to early April.
- Prevailing winds are northeasterly (trade winds)handli

OPERATIONAL INFORMATION

Handling Agent	SWISSPORT
Handling Agent VHF	-
Potable Water	Uplift permitted

IF ONLY Electrical Power is required	Use ground power at all times
IF BOTH electrical power and air conditioning is required:	Use both ground services at all times